


Fold 1



Next

Press the GREEN Next button on your rem

Press the green button to proceed with the installation.

Next
Pr

Press ⋆or ▾ and OK to select your language. Press the green button

The complete User Manual is available at www.magnavox.com/usasupport.

to continue with the installation.





If you are receiving channels via a cable receiver box, press the red button to exit. If you are receiving channels via a cable wall socket or antenna,



Select Antenna or Cable and press the green button to complete the installation.

The complete User Manual is available at www.magnavox.com/usasupport.





Press POWER button to switch on

TV after connecting AC power cord.


Specification

and antenna

Model no. Aspect Ratio Resolution Brightness Response Time (on/off) Viewing Angles (V/H) Sound output (RMS Watts) Sound modes Video formats Smart modes Rear connectors	16:9 1440x900p 300 cd/m2 5ms (typ.) 160 by 160 SO 3 W x 2 Mono, Ster
Aspect Ratio Resolution Brightness Response Time (on/off) Viewing Angles (V/H) Sound output (RMS Watts) Sound modes Video formats Smart modes	1440x900p 300 cd/m2 5ms (typ.) 160 by 160 SO 3 W x 2 Mono, Ster Automatic Super Zoc Personal, S
Aspect Ratio Resolution Brightness Response Time (on/off) Viewing Angles (V/H) Sound output (RMS Watts) Sound modes Video formats Smart modes	1440x900p 300 cd/m2 5ms (typ.) 160 by 160 SO 3 W x 2 Mono, Ster Automatic Super Zoo Personal, S
Resolution Brightness Response Time (on/off) Viewing Angles (V/H) Sound output (RMS Watts) Sound modes Video formats Smart modes	1440x900p 300 cd/m2 5ms (typ.) 160 by 160 SO 3 W x 2 Mono, Ster Automatic Super Zoo Personal, S
Brightness Response Time (on/off) Viewing Angles (V/H) Sound output (RMS Watts) Sound modes Video formats Smart modes	300 cd/m2 5ms (typ.) 160 by 160 SO 3 W x 2 Mono, Ster
Response Time (on/off) Viewing Angles (V/H) Sound output (RMS Watts) Sound modes Video formats Smart modes	5ms (typ.) 160 by 160 SO 3 W x 2 Mono, Ster Automatic Super Zoo Personal, S
Viewing Angles (V/H) Sound output (RMS Watts) Sound modes Video formats Smart modes	3 W x 2 Mono, Ster
Sound output (RMS Watts) Sound modes Video formats Smart modes	SO 3 W x 2 Mono, Ster Automatic Super Zoo Personal, S
Video formats Smart modes	3 W x 2 Mono, Ster Automatic Super Zoo Personal, S
Video formats Smart modes	Mono, Ste Automatic Super Zoo Personal, S
Video formats Smart modes	Automatic Super Zoo Personal, S
Smart modes	Super Zoo Personal, S
Smart modes	Super Zoo Personal, S
	Personal,
Rear connectors	AV1: Com
Real Connectors	AV 1. COII
	HDMI (Ve
	SPDIF out
0.1	PC IN: VO
Side connectors	Headphor
	Composit
Cuana waish:	W
Gross weight	13.4 lbs
Net weight	11.4 lbs
Box dimension (LxWxH)	20.3" x 17
Product dimension (HxWxD)	15.1" x 18
Power consumption	50W
Standby power consumption	<1W
Mains Power	100-120 V

Connect the AC power cord Connect to PC


Fold 4




The complete User Manual is available at www.magnavox.com/usasupport.

Wall Mount

When installing the LCDTV on the wall, please consult a professional technician for proper installation. The manufacturer accepts no liability for installations not performed by professional technician.



Metric 4 (10mm) screws are needed for wall mounting (not included).




19MF338B

The complete User Manual is available at www.magnavox.com/usasupport.





2



The complete User Manual is available at www.magnavox.com/usasupport.


To purchase a bracket, visit www.shoppings.philips.com/wallmounts.






This worronty gives you specific legal rights. You may have other rights which vary from state/province to state/province.

Magnavox, P.O. Box 671S39, Marietta, Ga. 30006-0026





Note: The TV is never powered off

COLOR BUTTONS

Press to select a task.

Selecting other devices.

CURSOR AND OK BUTTONS

Press ▲ , ▼ or ◀ , ► to navigate

the TV menu. Press OK to

confirm selection.

SOURCE

MENU/EXIT

SMART

VOL CH

1 2 3

4 5 6

7 8 9

PREV CH) 0

MAGNAVOX

completely unless it is physically unplugged.

Press menu to activate on-screen menu on/off.

